

Flexibler Gartenschlauch



10027112 10027113 10027114
10027115 10027116 10027117
10029005 10029006

DURAMAXX

Sehr geehrter Kunde,

Wir gratulieren Ihnen zum Erwerb Ihres Gerätes. Lesen Sie die folgenden Anschluss- und Anwendungshinweise sorgfältig durch und befolgen Sie diese, um möglichen technischen Schäden vorzubeugen. Für Schäden, die durch Missachtung der Sicherheitshinweise und unsachgemäßen Gebrauch entstehen, übernehmen wir keine Haftung.

Technische Daten

Artikelnummer	Länge ausgezogen in m
10027112	15
10027113	15
10027114	22,5
10027115	22,5
10027116	30
10027117	30
10029005 (ohne Brause)	30
10029006 (ohne Brause)	30

Sicherheitshinweise

- Stellen Sie keine schweren Gegenstände auf dieses Gerät.
- Stellen Sie keine Quellen offener Flammen, z.B. brennende Kerzen, auf das Gerät.
- Trinken Sie nicht aus dem Schlauch! Es handelt sich um ein Werkzeug für den Garten und ist daher für Menschen ungesund oder gefährlichen Stoffen ausgesetzt. Der Schlauch könnte in Kontakt mit Bakterien, Schimmel, Gartenchemikalien wie Dünger, Pestiziden oder Insektenvernichtungsmitteln, abgestandenem Wasser oder tierischen Exkrementen gekommen sein.
- Der Wasserschlauch ist kein Spielzeug! Lassen Sie keine Kinder mit dem Gerät spielen, beachten Sie insbesondere die Verletzungsgefahr durch Ersticken und die Möglichkeit des Verschluckens von Teilen.
- Ziehen Sie den Schlauch nicht auseinander, wenn kein Wasser hindurchläuft. Das Gerät ist dafür nicht geeignet. Wird der Schlauch in die Länge gezogen, wenn kein Wasser hindurch läuft, kann er beim Zurückschnellen Verletzungen verursachen. Vorsicht.
- Lassen Sie das Wasser hinauslaufen, wenn Sie das Gerät nicht benutzen.
- Lagern Sie das Gerät im Sommer an einem trockenen und schattigen Ort und im Winter im Innenraum, wo der Gartenschlauch keinem Frost ausgesetzt ist.

#

Nutzungshinweise

- Bevor Sie den Wasserschlauch benutzen, stellen Sie sicher, dass der Dichtungsring in der Muffe am Schlauchende fest und sicher an seinem Platz ist.
- Gehen Sie bei der ersten Benutzung besonders sorgsam mit dem Gerät um - strecken und entspannen Sie den Gartenschlauch bei wenig Wasserdruck zunächst langsam, um sich mit den Zugkräften vertraut zu machen.
- Schrauben Sie das ‚weibliche‘ Ende des Schaluchs an Ihren Garten- oder Garagen-Wasserhahn.
- Befestigen Sie am anderen Ende den Sprüh-Aufsatz.
- Stellen Sie sicher, dass das Ventil auf „OFF“ steht, also geschlossen ist, während Sie den Wasserhahn aufdrehen und den Druck langsam erhöhen. Der Gartenschlauch wird sich au-

tomatisch ausdehnen, bis er (maximal) die dreifache Länge erreicht hat.

- Nutzen Sie das Gerät nun wie jeden herkömmlichen Wasserschlauch.
- Wenn Sie die Wasserzufuhr abdrehen, zieht sich der Schlauch zu seiner ursprünglichen Länge zusammen. Lassen Sie dazu das Ventil geöffnet („ON“)
- Sie können diesen Gartenschlauch auch in Kombination mit einer Sprinkleranlage nutzen. Bitte beachten Sie aber, dass der Schlauch sich dabei öfters entfalten und wieder zusammenziehen könnte. Dies schadet dem Schlauch zwar nicht, kann aber das Unfallrisiko erhöhen.

Hersteller

Der Hersteller dieses Produktes ist die Chal-Tec GmbH, Wallstraße 16, 10179 Berlin.

Important Safety Instructions

- Do not place on or near a hot gas or electric burner or in a heated oven
- Do not expose the appliance to extreme temperatures. The appliance shall be used in moderate climates.
- The appliance is not a toy. Do not let the children play with it. Never let children insert foreign objects into the appliance.
- **Do not drink water from the hose!** As this is a gardening tool, it may have contact with bacteria, mold, insecticides, pesticides, other chemicals used within this context, animal waste, insects, stagnant water or other harmful substances.
- Do not unfold the hose when it is not filled with water. This may cause damage to the hose and it may cause accidents as the hose may be released accidentally.
- Pour the water out of the hose when it's not in use.
- Store the hose in a dry and shaded place in summer. In winter make sure the device is not exposed to harsh temperatures that can cause damage to the material.

Usage

- Before using the hose, place the rubber washer firmly inside the female coupling. Be very careful when first using the hose. It is recommended to first fill and extend it slowly at first use.
- Attach the female end to your water supply and the male end to the supplied valve. Turn the valve to the OFF position first.
- Turn on the water slowly until pressure increases. The hose should inflate automatically by this.
- Turn on the valve now to use the appliance like any ordinary hose. After use, the hose will deflate to its ordinary length pouring the water out. Leave the valve open („ON“) for this purpose.
- You can also use the hose combined with a sprinkler unit. Attach to the sprinkler nozzle and make it point away from you. Turn the valve to the ON position and walk away. The hose will act like any ordinary hose would.

Manufacturer

Chal-Tec GmbH, Wallstraße 16, 10179 Berlin. Germany

Technical Data

Item number	Extended length in m
10027112	15
10027113	15
10027114	22,5
10027115	22,5
10027116	30
10027117	30
10029005 (without spray nozzle)	30
10029006 (without spray nozzle)	30

Important Safety Instructions

- Do not place on or near a hot gas or electric burner or in a heated oven
- Do not expose the appliance to extreme temperatures. The appliance shall be used in moderate climates.
- The appliance is not a toy. Do not let the children play with it. Never let children insert foreign objects into the appliance.
- **Do not drink water from the hose!** As this is a gardening tool, it may have contact with bacteria, mold, insecticides, pesticides, other chemicals used within this context, animal waste, insects, stagnant water or other harmful substances.
- Do not unfold the hose when it is not filled with water. This may cause damage to the hose and it may cause accidents as the hose may be released accidentally.
- Pour the water out of the hose when it's not in use.
- Store the hose in a dry and shaded place in summer. In winter make sure the device is not exposed to harsh temperatures that can cause damage to the material.

Usage

- Before using the hose, place the rubber washer firmly inside the female coupling. Be very careful when first using the hose. It is recommended to first fill and extend it slowly at first use.
- Attach the female end to your water supply and the male end to the supplied valve. Turn the valve to the OFF position first.
- Turn on the water slowly until pressure increases. The hose should inflate automatically by this.
- Turn on the valve now to use the appliance like any ordinary hose. After use, the hose will deflate to its ordinary length pouring the water out. Leave the valve open („ON“) for this purpose.
- You can also use the hose combined with a sprinkler unit. Attach to the sprinkler nozzle and make it point away from you. Turn the valve to the ON position and walk away. The hose will act like any ordinary hose would.

Manufacturer

Chal-Tec GmbH, Wallstraße 16, 10179 Berlin. Germany